


Spare parts list

118/4 Orchestra music stand

11841-000-02 - chrome stand, walnut wooden desk

*Rev01



Position	Description	Article No.	Quantity
1	Base with legs	3-00-000-083	1
2	End cap	01-84-980-55	3
3	Knurled screw with logo M6 x 22 mm	01-82-948-55	1
4	Knurled screw with logo M6 x 10 mm	01-82-936-55	2
5	Screw connection of the music desk	3-00-000-065	1
6	Music desk	03-55-165-00	1
7	Knurled screw without logo M6 x 22 mm	01-82-837-55	1