


Spare parts list

101 Music stand

10100-013-11 - nickel-colored

*Rev01



Position	Description	Article No.	Quantity
1	Music stand bottom part	3-00-000-014	1
2	End cap	01-94-550-55	3
3	Clamp screw connection	3-00-000-012	1
4	Knurled screw with logo M5 x 9 mm	01-82-802-55	2
5	Screw connection of the music desk	3-00-000-011	1
6	Music desk complete	6-10100-1-11	1