


Spare parts list

107 Music stand

10700-000-11 - nickel-colored

*Rev01



Position	Description	Article No.	Quantity
1	Music stand bottom part	3-00-000-053	1
2	End cap	01-84-720-55	3
4	Clamping screw M6 x 11 mm	01-83-050-55	3
5	Screw connection of the music desk	3-00-000-005	1
6	Music desk complete	6-10700-1-11	1