


101 Music Stand

10100.000.01 nickel


10100.000.02 chrome



pos.	description	art.-no. nickel	art.-no. chrome	qty
1	leg cap	01.94.550.55	01.94.550.55	3
2	thumb screw	03.06.630.01	03.06.630.02	3
3	carriage bolt M5 x 15 mm	03.07.120.01	03.07.120.29	1
4	desk complete	6.10100.1.01	6.10100.1.02	1
4.1	flat-head rivet	03.62.065.01	03.62.065.01	2
4.2	swivel connector	01.44.520.01	01.44.520.02	1
5	assembly clamp complete, consisting of:	7.101.000401	7.101.000402	1
5.1	spherical head rivet 3 x 10 mm	03.61.060.01	03.61.060.01	3
5.2	clamp	01.35.315.01	01.35.315.02	3
6	upper assembly clamp cpl., consisting of:	7.101.000201	7.101.000202	1
6.1	threaded clamp side	01.36.334.01	01.36.334.02	1
6.2	clamp	01.35.310.01	01.35.310.02	2
6.3	spherical head rivet	03.61.055.01	03.61.055.01	1
5.1	rivet 3 x 10 mm	03.61.060.01	03.61.060.01	2
7	wing nut M5	03.22.681.55	03.22.681.55	1
8	washer ø 5,3 mm	03.11.310.29	03.11.310.29	1

101 Music Stand

10100.000.55 black



pos.	description	art.-no.	qty
1	leg cap 9 x 3 mm	01.94.550.55	3
2	knurled knob M5 x 9 mm	01.81.910.55	1
3	knurled knob M5 x 9 mm	01.81.285.55	2
4	carriage bolt M5 x 15 mm	03.07.120.01	1
5	swivel connector	01.44.522.01	1
6	rivet ø 3 x 6,5 mm	03.62.053.29	2
7	desk complete	6.10100.1.55	1
8	guide bush	01.86.285.55	1
9	washer ø 5,3 mm	03.11.310.29	1
10	locking knob M5	03.22.681.55	1