


Spare parts list

12179 Music stand

12179-000-55 - black

*Rev01



Position	Description	Article No.	Quantity
1	Base complete	6-12178-1-55	1
2	Plastic locking spacer	6-86740-1-55	1
3	Knurled screw with logo M6 x 22 mm	01-82-838-55	2
4	End cap	01-84-875-55	3
5	Tube combination with folding square	3-00-000-067	1
6	Screw connection of the folding square	3-00-000-066	1
7	Music desk	02-50-123-55	1
8	Accessories bag	6-12178-2-00	1
9	Countersunk flat head tapping screw	03-02-655-25	1