


Spare parts list

10040 Music stand

10040-000-55 - black

*Rev01



| Position | Description | Article No. | Quantity |
|----------|------------------------------------|--------------|----------|
| 1 | Music stand bottom part | 3-00-000-055 | 1 |
| 2 | End cap for profile foot | 01-84-650-55 | 3 |
| 3 | Knurled screw with logo M6 x 16 mm | 01-82-834-55 | 3 |
| 4 | Screw connection of the music desk | 3-00-000-054 | 1 |
| 5 | Music desk complete | 6-10040-1-55 | 1 |