


Spare parts list

# 10065 Music stand

10065-000-11 - nickel-colored

\*Rev01



Position	Description	Article No.	Quantity
1	Countersunk-head tapping screw	03-02-655-25	1
2	Base complete	6-10065-2-11	1
3	Clamping element with pin R8	01-86-634-55	1
4	Square nut M6	03-08-305-29	1
5	Knurled screw with logo M6 x 16 mm	01-82-834-55	3
6	End cap	01-94-660-55	3
7	Rod combination complete	6-10065-3-11	1
8	Screw connection of the music desk	3-00-000-005	2
9	Music desk complete	6-10065-1-11	1