


Spare parts list

# 14315 Soprano saxophone stand

14315-000-55 - black

\*Rev01



Position	Description	Article No.	Quantity
1	End cap	01-84-882-55	3
2	Knurled screw with logo M6 x 22 mm	01-82-838-55	1
3	Saxophone rest	01-89-100-55	1