


Spare parts list

100/1 Music stand

10010-000-54 - blue

*Rev01



Position	Description	Article No.	Quantity
1	Music stand bottom part	3-00-000-058	1
2	End cap for profile foot	01-84-650-55	3
3	Knurled screw with logo M6 x 16 mm	01-82-834-55	3
4	Screw connection of the music desk	3-00-000-054	1
5	Music desk complete	6-10010-1-54	1