


# 14340 Saxophone Stand » Saxxy«

14340.000.55 black

## SPARE PARTS INSTRUMENT STANDS



pos.	description	art.-no.	qty
1	end cap ø 10 mm	01.84.965.55	7
2	supporting tube left / stand tube ø 10 mm	02.80.200.55	3
3	supporting bolt ø 10 mm	01.02.272.55	2
4	EJOT screw ø 4 x 20 mm	03.06.135.29	3
5	carriage bolt M8 x 50 mm	01.09.084.55	1
6	cylindrical pin ø 2 x 14 mm	03.14.520.00	4
7	upper connecting element	01.84.040.55	1
8	lower connecting element	01.84.042.55	1
9	washer ø 8,4 mm	03.11.520.25	1
10	stand tube ø 12 mm, M8	01.03.670.55	1
11	supporting tube right ø 10 mm	02.80.195.55	1
12	rubber ring ø 10 mm	01.84.552.55	6
13	supporting cord	03.19.120.00	1