

14330

Saxophone stand »Jazz«

Product variant

14330-000-55 - black

Data

central locking screw
4016842816231
0.276 kg
310 mm
non-marring material
aluminum
folds very small; easy-to-use; can be transported in the supplied velour bag in the saxophone bell; embedded foot end caps
Eb alto saxophones
black

Practical, easy to use and stable stand for Eb alto saxophones. Solid square-type aluminum tubes with a large central locking screw, protective rubber bumps where the stand connects with the saxophone body and the bell. Embedded foot end caps. Folds compactly, can be transported in the supplied velour bag in the saxophone bell.

