

## 21445

# Leveling leg for speaker stand

### Product variant

21445-000-55 - black

### Technical Data

#### Visibility

|                                 |        |
|---------------------------------|--------|
| Height                          | 25.47" |
| Suitable for tubing diameter of | 1.378" |
| Type                            | black  |

#### Price display

|                  |                                                                                                                                                                                                                             |
|------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Special features | with the help of this adapter you can easily balance out uneven surfaces, stairs, steps or sloped surfaces of max. 200 mm; if the surface is even, you simply leave the adapter in the initial position on the speaker foot |
|------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

|          |       |
|----------|-------|
| Material | steel |
| Diameter | 1.57" |



Adapt your speaker stand to the respective stage, studio or practice room using this leveling leg - a useful supplement for the following König & Meyer speaker stands: 21300-009-55, 21302-009-55, 21435-177-55, 21436-177-55, 21460-177-55, 21460-177-76, 21463-000-55, 21467-000-55, 24630-009-55, 21471-000-55 and 21472-000-55. With the help of this adapter you can easily level uneven surfaces, stairs, steps or sloped surfaces. The leveling leg is attached to one of the speaker feet and set using a clamping bracket. The required leveling length is variable and allows a height adjustment of max. 7.874". If the surface is even, you simply leave the adapter in the initial position on the speaker foot.