

14300 Saxophone stand

Product variant

14300-000-55 - black

Technical Data

Visibility

Leg construction	socket with foldable legs
Musikinstrument	Eb alto saxophone
Height	19.09"
Instrument support	non-marring material
Type	black
Special features	fiberglass reinforced plastic base; flexible upper support arm; lower support arm bracket with several vertical locking positions

Price display

Material	steel
Musikinstrument	Bb Tenor saxophone
Suitable for	Eb Alto and Bb Tenor Sax



Adjustable folding stand for Eb Alto and Bb Tenor Sax. Fiberglass reinforced plastic base. Flexible upper support arm for different bell sizes. Lower support arm bracket with several vertical locking positions. All instrument support parts covered with exclusive non-marring plastic coating. To be used with peg holder 14301 and clarinet peg or with peg holder, adapter 15281 and pegs for trumpet, soprano sax or flugelhorn.